



# TMC CORE PIPE ASSEMBLIES



TANGENTIAL VALVE IN  
CORE PIPE ELBOW ASSEMBLY

Core pipe assemblies allow close mounting of the valve to the core to eliminate flanges, dead spots and heat losses. The valves can be welded to the core in **parallel** to the flow, **perpendicular** to the flow or **tangent** to the flow depending on the desired effect.

Core pipe assemblies are most often used for vent and drain service, or in smaller port sizes they are excellent for injecting solvents, colorants or additives.



TANGENTIAL VALVE AND  
PERPENDICULAR VALVE IN  
SAME CORE PIPE

