

Sampling Valves



Threaded Sampling Valves
Jacketed Valves
Actuated Valves
Injection Valves
Non-plugging designs




The primary purpose of a Sample valve is to be able to provide the operator with a clean sample direct from a pipeline or a vessel. The common principle in all three of our design types is that the port is filled with a plunger that prevents stagnant build up in between sample operations. We offer valves with the seals in different locations so that the design can be modified depending on your process needs. The Sample valve can also be used for a variety of purposes:



Common Accessories include:

- Fully welded integral jacket
- Actuators, Air motor, Air cylinder, Electric motor, Gear box
- Contoured half coupling; To fit valve flush to the ID of pipe or vessel
- Piping Tee
- Sample bottle adapter
- Lock out tag out devices






The drawing above shows the two most common methods of attaching Sample valves to the process line. Both are designed to place the valve seal as close as possible to the ID of the pipe. There are many other methods available such as butt or socket weld. Contact us to see if we can mount it the way that you envision it.

For injection service we will weld or flange the valve to the pipe so that the injection point is projected inside the pipe.

- product sampling
- Injection Valve
- Vent Valve
- Drain Valve
- Kill solution valve
- Nozzle Rodding
- Bypass loop valve

Body Seal Design

Sizes 1/2" to 1 1/2" Smooth bore plunger, seatless design



Above example is shown is our Body seal Design it uses resilient seal rings (p/n 11) to seal against the plunger. It is shown as a 60 degree cast body design. It is also available as a 45 degree fabricated body design.


Metallurgy and options available on the back page of the brochure (page 8)

Size	Figure	PORT ID
1/4X 1/4	BS-002-M	.250
3/ _{8× 1/4}	BS-004-M	.312
½x ½	BS-005-M	.432
3/4X 1/2	BS-005-M	.437
3/4X 3/4	BS-007-M	.625
lx 3/4	BS-007-M	.625
I ½ x I	BS-010-M	1.0

Plunger Seal Design

Sizes 1/2" to 1 1/2"

Seal on plunger, seated design



Above example is our Plunger Seal design it has the seal components on the plunger, so that when the plunger strokes to the open position, the seal parts are retracted out of the flow. It is shown as a 45 degree fabricated body design. It is also available as a 60 degree cast body design.

Metallurgy and options available on the back page of the brochure (page 8)

This Valve design lends it self to the extended body concept that allows custom fitting of the valve to your process connection. The valve port can be reduced to .125" for injection applications.

Size	Figure	Port ID
½ x ½	PS-005-M	.438
3/4X 1/2	PS 005-M	.438
lx ½	PS-005-M	.438
3/4 X 3/4	PS-007-M	.562
lx 3/4	PS-007-M	.562
lxl	PS-009-M	.750
lxl	PS-010-M	.938
l½ xl	PS-011-M	1.062

Sample Valves page 6

Core Pipe Assemblies

Purpose:

Weld valve directly into piping system

Reason:

Fewer flange connections

Closer location of seal to process

Better fit and function

Easier field installation

Plunger end contoured to fit the pipe core

Better Jacketing design for more efficient

Function:


Sampling Valve

Vent Valve

Line Drain Valve

Injection Valve

Instrumentation Loop Valve





Corepipe Assembly with Flanged Mounting Pad



Other special designs include

Sample Valve Wafer Valve, with Locking Device

Short Stroke Poppet Sample Valves

Options include:

- Position Indicating Switches
- Welded Integral Heat Jacket
- Actuation
- Bottle adapter
- Port diameters down to 1/8"
- Lock Out /Tag Out Designs
- Flush Port
- Custom Designs


Metallurgy Availability:

All component material can be user selected

- 316/L SS
- Alloy C22
- Titanium
- Nickel
- Alloy 20
- 2205

Fabricated and cast bodies available in any castable / machinable materials that your process demands

Tretter Manufacturing Company



Lansdale, PA 19446 Phone : Cell 610-507 7783 Fax 800-859-8495 Email: trettermanco@aol.com www.tmcvalves.com

451 N. Cannon Ave

Made in the USA